





TERMS OF BUSINESS AND LEGAL DISCLAIMERS

Hilti strives to achieve continuous development and innovation. This manual is thus subject to change without notice. Hilti strongly advises customers to verify the respective product application for the intended use by consulting a structural engineer and making the necessary calculations to ensure compliance with the applicable norms and standards. It is essential that the product is used strictly in accordance with the applicable Hilti instructions for use and within the application limits specified in the Hilti technical data sheets, technical specifications and supporting product literature. Due to the fact that construction materials and environmental conditions vary widely, information given in this manual is solely based on principles and safety factors believed to be correct at the time they were established. The customer is ultimately responsible for checking the present condition of supporting materials and the applicability of the selected product application. Hilti shall not be liable for direct, indirect, incidental or consequential damages, losses or expenses in connection with any information contained in this manual or in connection with, or by reason of, the use of, or inability to use the products for any intended purpose. This limitation of liability does not apply to personal damages culpably caused by Hilti. Implied warranties of merchantability or fitness of the products are herewith expressly excluded.

NAMING CONVENTIONS USED IN THE MANUALS FOR TYPICAL APPLICATIONS





CONTENTS AND OVERVIEW OF THIS MANUAL

Sections	Page
1 Basics	
2 General requirements/European regulations	
3 Panels and systems	
4 System descriptions	
5 Load tables	
6 U-Value	